



Door controls

- A** Rear view mirror, select and adjust.
- B** Heating on all four mirrors, on/off.
- C** Window winder left/right, with express down (activate 0,5 sec).



Digital Instrument Panel (DIP)

- A** Information bar with status of warnings, alarm, AS-Tronic gear, cruise-/down hill speed control and telephone.
- B** Information screen (red, vital warnings).
- C** Information screen (yellow warnings). Press Menu Selector Switch to access main menu. Scroll and press to select.




Menu Selector Switch Digital Instrument Panel (DIP)

Press to access main menu. Scroll and press to select.

Menu's are:

- vehicle info
- fuel consumption
- warnings
- boost pressure
- trip info
- next service
- settings
- PTO counter




Remote control

Setting chassis height, with 2 memory settings and automatic setting of driving height.

Version with Axle Load Monitoring:

- Also calibration of axle load values (preferably 1/year).



Steering column stalk (left)

- Centre position (dipped beam, lights on).
- A** Headlight flash. **B** Main beam.
 - C, D** Direction indicator left/right.
 - E** Horn.
 - F** Windscreen washer.
 - G** Windscreen wiper.
 - Intermittent wipe (interval time set by on, time off, on).
 - 0, 1, 2** Wipers off, low- and high speed.



Steering wheel buttons (left)

- A Top:** accept call. **Bottom:** end or reject call.
- B Select driving:** 1 of last 10 calls. **Select stationary:** listing phonebook.
- C Downhill speed control (optional).** **Set:** current speed set for descent. **Set on flat road with cruise control on:** cruise speed + 3 kmh.



Steering column stalk (right)

- 1** Manual gearbox and **MX engine brake (only CF85).**
 - Engine brake on/off (gas throttle overrules setting, gear changing not).
 - Speed limiter set/off.
 - Cruise control set/resume/off.
- 2** Manual gearbox and **Intarder.**
 - 1/3, 2/3, full intarder operation.



Lighting switch

- 1** Parking and marker lights on.
- 2** Headlamps, parking and marker lights on.



Manual gearbox

- Depending on vehicle configuration.
- A** (Pre)select range at front side gearlever.
 - B** Half ranging (splitting) at the side of the gearlever.



Automated gearbox

- N** Neutral.
 - D** Drive.
 - R** Reverse.
- And manoeuvring positions (adjusted gas throttle settings for slow, flowing movement. Limited torque/rev and clutch slip). For automatic gearboxes on CF75 and CF65 check the driver manual.



1 AS-Tronic and MX engine brake.

- Engine brake on/off (gas throttle overrules setting, gear changing not).
 - Auto/manual.
 - Shift up/down (one click, one gear).
- 2 AS-Tronic and Intarder.**
- AS-Tronic use similar.
 - 1/3, 2/3, full intarder operation.
- The optional MX engine brake integrated at full Intarder operation.



Heating & ventilation

- 1 Fan speed.
- 2 Air distribution.
- 3 Air temperature.

4 Automatic Temperature Control

- Set temperature is thermostatically controlled.
- Fan speed and air distribution to own preference.



Centre console

- 1 Flasher hazard warning lights.
- 2 Main switch.
- 3 ASR (slightly more traction at low speed, by allowing wheel slip).
- 4 Pos. 1: night light (no reflections whilst driving).
- 5 Interior light off (all off and remain off).
- 6 Roof hatch.
- 7 Cab heater.
- 8 Unlocking co-drivers door.
- 9 Spare.
- 10 Interior light (hotel switch with bed position).



Control panel

- 1 Spare.
- 2 Resume normal driving height (air suspension).
- 3 Hill start aid.
- 4 Airconditioning (not active when blower position 0).
- 5 Recirculation valve (use short periods of time only).



- 6 Cross-axle differential lock.
- 7 Traction control.
- 8 Lane departure warning.
- 9 Spare.
- 10 Reverse buzzer.
- 11 Third brake integration (off only when noise of retarders is unacceptable).
- 12 Spare.
- 13 Spare.



Dashboard panel (left)

- 1 Work lamp/ load space lighting.
- 2 Front/rear fog lights.
- 3 Headlamp height adjustment.
- 4 Dimming instrument panel.
- 5 Taillift.
- 6 Taillift active indication.
- 7 Interior light off (all off and remain off).



Dashboard panel (right)

- 1 PTO 1.
- 2 PTO 2.
- 3 PTO 3.

Please note specific vehicle configurations may differ from these instructions.

DW141969/GB:0506



Enjoy your new DAF CF. Please read these instructions to ensure that you quickly feel at ease in the CF. Full details are available in the driver's handbook.

Quick Guide DAF CF Series

